
Please add Wechat if the line is busy.



#### Note:

1. The installation instructions may differ slightly from the actual operation. If there are any differences, please follow the actual situation or contact us. 2. Warning: Please do not disassemble any part by yourself, any improper operation will not be covered by our warranty.



### **Tesla MODEL X Kick Sensor Installation Guide**

1. The installation instructions may differ slightly from the actual operation. If there are any differences, please follow the actual situation or contact us. 2. Warning: Please do not disassemble any part by yourself, any improper operation will not be covered by our warranty.

After-sales Service: +86 1552108 2760 (WhatsApp, Skype, Phone & Wechat) Please add Wechat if the line is busy.

#### Remove trunk trims

Open the trunk, follow the steps as shown and remove the trims one by one.



### Remove side trims

The picture illustrates how to remove trim①②.



# Remove bottom trims

Take off the trim buckles after removing trim<sup>(3)</sup>.



### 4 Remove side trims

First remove the screws at the marked position, then remove trim ④.



#### Remove side trims

First remove the five screws at the marked position, then remove trim(§).



### 6 Remove side trims

The picture after trim<sup>⑤</sup> is removed.



# Remove underbody

Take off the two buckles as shown, and remove the trim



## Remove underbody trim

Clean the trim inner surface, attach the kick sensor to it with the supplied double-stick tape as shown (Note the "this side up" label).



### Sick sensor wiring diagram


Lift up the trunk bottom trim, pass the cables out of the car through the holes indicated by the arrow, and connect the sensors.





# Control box installation position

Attach the control box behind the left trim of the trunk with double-stick tape



# Wiring diagram of the Ground (GND)



