

Installation Instructions for the Tesland Autolift 2.0

Thank you for purchasing our Autolift . We hope that you are satisfied with the product!

Please read these instructions before installing the product. Although the installation is not hard and does not require any special skills, it can be handy to have some general knowledge of mechanics.

If you have any doubt doing this after reading these instructions, we recommend that you have the Autolift installed by a local professional. If you need to contact us, please use the information on our website. www.tesland.nl

Precautions and general notes.

All rights reserved. No parts of this manual may be reproduced in any form without the express written permission of Tesland.nl.

Tesland.nl makes no representations or warranties with respect to the contents hereof. In addition, information contained herein are subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, Tesland.nl assumes no responsibility for errors or omissions or any damages resulting from the use of the information contained in this publication.

Tesland.nl does not take any responsibilities if during the installations anything goes wrong.

Tesland.nl can never be held responsible for replacement of any parts which will break during the installation, even when following these guidelines.

To use these instructions, we recommend that you will have a look online for the latest version at www.tesland.nl.

Instructions:



Measure 27 cm's from the gap between the lower part of the rear hatch liner and the side part. Mark the position where the screw should be inserted.

Use a Philips #2 screwdriver and insert the screw until halfway. We do not recommend pre drilling, since there are electronics behind the plastic liner.



Now insert the pin through the rubber grommet as seen in the picture and push it into the parcelshelf at an angle of approximate 45 degrees forward. Be sure that the pin keeps centred in the parcel shelf, so it doesn't come out in the bottom or top.



Now connect the elastic wire to the screw and grommet, and you are finished.
If you need to remove the parcel shelf, we recommend releasing the wire from the screw.

Good luck!